

FINISHES



EPB
POLISHED BRASS



EPC
POLISHED CHROME



ESC
SATIN CHROME

INTERIORS

B
BLACK

PBB
POLISHED BRASS SWITCH BLACK TRIM

PBW
POLISHED BRASS SWITCH WHITE TRIM

PCB
POLISHED CHROME SWITCH BLACK TRIM

PCW
POLISHED CHROME SWITCH WHITE TRIM

SCB
SATIN CHROME SWITCH BLACK TRIM

SCW
SATIN CHROME SWITCH WHITE TRIM

W
WHITE

CODES EXPLAINED

FINISH **PRODUCT CODE** INTERIOR

EXAMPLE

EPB**T2SW**

EuroLite
T 01772 672020 F 01772 672030
E sales@eurolite.co.uk W www.eurolite.co.uk

SWITCHES

1 GANG SWITCHES

10amp	1SW 10A1SW	10amp 1 Gang 2 Way Switch 10amp 1 Gang 2 Way Grid Switch
20amp	20ASW 20ASWN 20A1SW	20amp 1 Gang Switch 20amp 1 Gang Switch and Neon 20amp 1 Gang 2 Way Grid Switch
20amp Dp	20ADP1SW 20ADP1SWN 20ADP1SWCO	20amp 1 Gang Double Poled Grid Switch 20amp 1 Gang Double Poled Grid Switch and Neon 20amp 1 Gang Double Poled Grid Switch and Chord Outlet
20amp Intermediate	INT 20AINT	20amp 1 Gang Intermediate Switch 20amp 1 Gang Intermediate Grid Switch
Key Switches	K1SW	1 Gang Key Grid Switch
Triple Pole Fan Isolator	FSW	Fan Isolator Switch

2 GANG SWITCHES

10amp	2SW 10A2SW	10amp 2 Gang 2 Way Switch 10amp 2 Gang 2 Way Grid Switch
20amp	20A2SW	20amp 2 Gang 2 Way Grid Switch
20amp Dp	20ADP2SW	20amp 2 Gang Double Poled Grid Switch
20amp Intermediate	20A2INT	20amp 2 Gang Intermediate Grid Switch
Key Switches	K2SW	2 Gang Key Grid Switch

3 GANG SWITCHES

10amp	3SW 10A3SW	10amp 3 Gang 2 Way Switch 10amp 3 Gang 2 Way Grid Switch
20amp	20A3SW	20amp 3 Gang 2 Way Grid Switch
20amp Dp	20ADP3SW	20amp 3 Gang Double Poled Grid Switch

4 GANG SWITCHES

10amp	4SW 10A4SW	10amp 4 Gang 2 Way Switch 10amp 4 Gang 2 Way Grid Switch
20amp	20A4SW	20amp 4 Gang 2 Way Grid Switch
20amp Dp	20ADP4SW	20amp 4 Gang Double Poled Grid Switch
45amp Dp Switch and Neon	45ASWN 45ASWNS	45amp Switch and Neon 45amp Switch and Neon Single Plate
45amp Dp Switch and 13amp Socket	45ASWAS	45amp Switch and Socket

CONNECTION UNITS

13amp Switched Fuse	SWF SWFN SWFFO SWFNFO	Switched Fuse Switched Fuse and Neon Switched Fuse and Flex Outlet Switched Fuse Neon and Flex Outlet
13amp Unswitched Fuse	SUSWF USWFN USWFFO	Unswitched Fuse Unswitched Fuse and Neon Unswitched Fuse and Flex Outlet
Flex Outlet Plates	FO	Flex Outlet

DIMMER SWITCHES

250W 2 Way Push On/Off	1D250W 2D250W 3D250W 4D250W	1 Gang 250 Watt Dimmer 2 Gang 250 Watt Dimmer 3 Gang 250 Watt Dimmer 4 Gang 250 Watt Dimmer
400W 2 Way Push On/Off	1D400W 2D400W 3D400W 4D400W	1 Gang 400 Watt Dimmer 2 Gang 400 Watt Dimmer 3 Gang 400 Watt Dimmer 4 Gang 400 Watt Dimmer
250W Low Voltage 2 Way Push On/Off	1D250WI 2D250WI 3D250WI 4D250WI	1 Gang 250 Watt Inductive Dimmer 2 Gang 250 Watt Inductive Dimmer 3 Gang 250 Watt Inductive Dimmer 4 Gang 250 Watt Inductive Dimmer
400W Low Voltage 2 Way Push On/Off	1D400WI 2D400WI 3D400WI 4D400WI	1 Gang 400 Watt Inductive Dimmer 2 Gang 400 Watt Inductive Dimmer 3 Gang 400 Watt Inductive Dimmer 4 Gang 400 Watt Inductive Dimmer
1000W 2 Way Push On/Off	1D1000	1 Gang 1000 Watt Dimmer
1000W Low Voltage 2 Way Push On/Off	1D1000WI	1 Gang 1000 Watt Inductive Dimmer

TOGGLE SWITCHES

20amp 2 Way	T1SW T2SW T3SW T4SW	20amp 1 Gang Toggle Switch 20amp 2 Gang Toggle Switch 20amp 3 Gang Toggle Switch 20amp 4 Gang Toggle Switch
20amp Dp	TDP1SW TDP2SW TDP3SW TDP4SW	20amp 1 Gang Double Poled Toggle Switch 20amp 2 Gang Double Poled Toggle Switch 20amp 3 Gang Double Poled Toggle Switch 20amp 4 Gang Double Poled Toggle Switch
20amp Intermediate	TINT T2INT	20amp 1 Gang Intermediate Toggle Switch 20amp 2 Gang Intermediate Toggle Switch

SOCKETS

1 Gang 13amp Double Poled Twin Earthed SS	1SO	1 Gang Switched Socket
2 Gang 13amp Double Poled Twin Earthed SS	2SO	2 Gang 13amp Switched Socket
5amp Switched Socket	5ASO	1 Gang 5amp Switched Socket
Dual Voltage Shaver Socket	SH5	Shaver Sockets
Satellite and TV Sockets	SS STV 1TV 2TV STVFM	1 Gang Satellite Socket 1 Gang Satellite Socket and TV Socket 1 Gang TV Socket 2 Gang TV Socket 1 Gang Satellite TV and FM Outlet
Telephone Sockets	1M 2M 1S 2S 2RJ45	1 Gang Telephone Master Socket 2 Gang Telephone Master Socket 1 Gang Telephone Slave Socket 2 Gang Telephone Slave Socket 2 Gang Data Socket
Blank Plates	1B 2B	1 Gang Blank Plate 2 Gang Blank Plate



EDEN RANGE